STANLEY®

STANLEY TOOLS REPAIR PARTS CATALOG

Prices on Separate Sheet

No. RP186











TABLE OF CONTENTS

	Page
Bevels	17
Bit Braces	2
Bits, Expansive	2
Bolt Cutter	9
Coping Saws	9
Doweling Jig	3
Drills, Hand	3
Drills, Push, Yankee®	2
Garden Tools	20
Gauges	17
Knives	3
Level and Plumb Units	16
Hack Saw Parts	9
Mitre Boxes	10–15
Mitre Machine, Vises	12
Planes	4–8
Plumb Bob Tip	18
Push Drills, Yankee®	2
Rules, Belt Clips	16
Rules, Slide Locks	16
Rules, Springs	16
Saw Sets	9
Screw Drivers, Yankee®	18–19
Screw-Mates®, Adjustable	3
Shingle Hatchet	18
Squares	17
Tap Wrenches, Yankee®	19
UniTrack™ Merchandiser Components	20
Vises	20











Stanley Tools, Division of The Stanley Works, New Britain, Connecticut 06050, U.S.A.

WHEN ORDERING REPAIR PARTS ALWAYS GIVE THE FOLLOWING INFORMATION:

1. The Reference Number in this List.
2. The Part Name in this List.

This catalog is designed to help owners of Stanley Tools identify and order interchangeable repair parts that can be easily replaced without the aid of special tools or equipment. We recommend that the owner make his own repairs whenever it is possible and thereby save the expense of round trip transportation of tools in addition to the repair cost.

When ordering, be sure to specify the reference number and name.

Expansive Bits

Key	Part Name	01-710 Ref. No.	01-711 Ref. No.
1.	Cutter (1⅛ to 1¾)	01-710-1	—
2.	Cutter (⅝ to 1⅛)	01-710-2	—
3.	Cutter (1¾ to 3)	—	01-711-3
4.	Cutter (⅞ to 1¾)	—	01-711-4

Bit Braces



Key	Part Name	02-253 (H1253A) Ref. No.	02-923 02-922 (923A) Ref. No.	02-945 02-942 (945A) (945B) ★ Ref. No.
1.	Chuck Complete	02-253-1	02-923-1	02-945-1
2.	Type G Jaws	—	02-923-2	—
3.	Type I Jaws	—	—	02-945-3
4.	Type J Jaws	02-253-4	—	—
5.	Shell	02-253-5	02-923-5	02-945-5
6.	Head	02-253-6	02-923-6	02-945-6
7.	Quill	02-253-7	02-923-7	02-945-7
8.	Nut & Pin	—	02-923-8	—
9.	Pawls (2)	02-253-9	02-923-9	02-945-9
10.	Pawl Pin	—	02-923-10	02-945-10
11.	Pawl Spring	02-253-11	02-923-11	02-945-11

★ **New Style I Jaws — 02-945B-3**

Yankee® Push Drill



Key	Part Name	03-043 (41Y) Ref. No.
1.	Magazine	03-043-1
2.	Main Spring Plug	03-043-2
3.	Magazine Nut Ring	03-043-3
4.	Magazine Nut	03-043-4
5.	Main Spring	03-043-5
6.	Chuck Screw	03-043-6
7.	Chuck Unit	03-043-7

Yankee® Push Drills

Key	Part Name	03-045 (45Y) Ref. No.	03-046 (46Y) Ref. No.
1.	Cap	03-045-1	03-046-1
2.	Main Spring	03-045-2	03-046-2
3.	Spring Plug	03-045-3	03-046-3

WHEN ORDERING REPAIR PARTS ALWAYS GIVE THE FOLLOWING INFORMATION:

1. The Reference Number in this List.
2. The Part Name in this List.

STANLEY helps you do things right.™

Hand Drills



Key	Part Name	03-222 (H1220B) Ref. No.	03-612 (611A) Ref. No.	03-624 (624A) Ref. No.
1.	Chuck Assembly	03-222-1	03-612-1	03-624-1
2.	Large Gear	03-222-2	03-612-2	03-624-2
3.	Pinion Gear	—	03-612-3	03-624-3
4.	Jaws & Spring	03-222-4	03-612-4	03-624-4
5.	Crank & Handle	03-222-5	03-612-5	03-624-5
6.	Side Knob	03-222-6	—	03-624-6
7.	Handle Cap	03-222-7	—	03-624-7
8.	Handle	03-222-8	03-612-8	—
10.	Crank Screw	—	03-612-10	03-624-10

Doweling Jig



Key	Part Name	EXTRA GUIDES — ORDER BY SIZE 04-059 (59) Ref. No.
*1.	Extra Guides	04-059-1
2.	V Block or Side Block	04-059-2
3.	V Block Screw	04-059-3
4.	V Block Adj. Screw	04-059-4
5.	Depth Gauge or Stop	04-059-5
6.	Depth Gauge Screw	04-059-6

* **Order by size:** 3/16", 1/4", 5/16", 3/8", 7/16", 1/2", 5/8", 9/16", 3/4"

Adjustable Screw-Mates®

Key	Part Name	04-621 Ref. No.	04-622 Ref. No.	04-623 Ref. No.	04-624 Ref. No.
1.	Pilot Drill	04-621-1	04-622-1	04-623-1	04-624-1
2.	Set Screw	04-621-2	04-622-2	04-623-2	04-624-2
3.	Sleeve Drill	04-621-3	04-622-3	04-623-3	04-624-3

Knives

Key	Part Name	10-099 (99A) Ref. No.	10-499 (28-499) Ref. No.
1.	Slide	10-099-1	10-499-1

Professional™ Planes

See pages 4 and 5.

Product Number	Description	Length Inches	Cutter Width Inches
12-003	#3 Professional Bench	9 1/4	1 3/4
12-004	#4 Professional Bench	9 3/4	2
12-005	#5 Professional Bench	14	2
12-006	#6 Professional Bench	18	2 3/8
12-007	#7 Professional Bench	22	2 3/8
12-014	#4C Professional Bench	9 3/4	2
12-015	#5C Professional Bench	14	2
12-020	9 1/2 Fully Adjustable Plane	6	1 5/8
12-220	220 Screw Adjustment Cutter	7	1 5/8
12-116	110 Wheel Adjustment Cutter	7	1 5/8
12-060	60 1/2 P Full Adj./Low Angle	6	1 3/8

Replacement Plane Cutters

Old Number	New Ref. Number	Fits
12-503	12-338	U.S.A. 60 1/2, 12-060
12-506	12-331	U.S.A. 9 1/2, 9 1/4, 118, 220, 12-019, 12-020, 12-118, 12-220
12-513	12-313	U.S.A. & Sheffield 4, 1204, 5, 1205, 12-005, 12-004, 12-204, 12-205, G12-204, G12-205, G12-004, G12-005, etc.
—	12-202	Sheffield G12-102
12-507	12-330	Sheffield G12-247, G12-116
—	12-504	Sheffield G12-060
—	12-508	Sheffield G12-020, G12-220

WHEN ORDERING REPAIR PARTS ALWAYS GIVE THE FOLLOWING INFORMATION:

1. The Reference Number in this List.
2. The Part Name in this List.

STANLEY helps you do things right™

Bench Planes with Smooth and Corrugated Bottoms

MADE IN U.S.A.



Key	Part Name	12-003 12-013 (3) (3C) Ref. No.	12-004 12-014 (4) (4C) Ref. No.	12-005 12-015 (5) (5C) Ref. No.	12-006 12-016 (6) (6C) Ref. No.	12-007 12-017 (7) Ref. No.	12-025 (5¼P) Ref. No.
1.	Plane Bottom - Smooth	12-003-1	12-004-1	12-005-1	12-006-1	12-007-1	12-025-1
1.	Plane Bottom - Corrugated	12-013-1	12-014-1	12-015-1	12-016-1	12-017-1	—
2.	Knob	12-003-2	12-004-2	12-005-2	12-006-2	12-007-2	12-025-2
3.	Lever	12-003-3	12-004-3	12-005-3	12-006-3	12-007-3	12-025-3
4.	Cutter	12-003-4	12-004-4	12-005-4	12-006-4	12-007-4	12-025-4
5.	Handle	12-003-5	12-004-5	12-005-5	12-006-5	12-007-5	12-025-5
6.	Frog Assembly	12-003-6	12-004-6	12-005-6	12-006-6	12-007-6	12-025-6
7.	Back Screw	12-003-7	12-004-7	12-005-7	12-006-7	12-007-7	12-025-7
8.	Cutter Adj. Nut	12-003-8	12-004-8	12-005-8	12-006-8	12-007-8	12-025-8
9.	Frog Screw (2)	12-003-9	12-004-9	12-005-9	12-006-9	12-007-9	12-025-9
10.	Cap Screw	12-003-10	12-004-10	12-005-10	12-006-10	12-007-10	12-025-10
11.	Cutter Cap	12-003-11	12-004-11	12-005-11	12-006-11	12-007-11	12-025-11
12.	Lever Screw	12-003-12	12-004-12	12-005-12	12-006-12	12-007-12	12-025-12
13.	Knob Screw	12-003-13	12-004-13	12-005-13	12-006-13	12-007-13	12-025-13
14.	Handle Screw	12-003-14	12-004-14	12-005-14	12-006-14	12-007-14	12-025-14
15.	Toe Screw	—	—	—	12-006-15	12-007-15	—
16.	Handle Nut	—	—	—	12-006-16	12-007-16	—
17.	Knob Nut	—	—	—	12-006-17	12-007-17	—
18.	Frog Adj. Screw	—	—	—	12-006-18	12-007-18	—
19.	Adjusting Clip	—	—	—	12-006-19	12-007-19	—
20.	Clip Screw	—	—	—	12-006-20	12-007-20	—

WHEN ORDERING REPAIR PARTS ALWAYS GIVE THE FOLLOWING INFORMATION:

1. The Reference Number in this List.
2. The Part Name in this List.

STANLEY helps you do things right.™

Bench Planes

MADE IN ENGLAND BY STANLEY



Key	Part Name	12-003 Ref. No.	12-004 12-014 Ref. No.	12-005 12-015 Ref. No.	12-006 12-016 Ref. No.	12-007 12-017 Ref. No.	12-203 Ref. No.	12-204 Ref. No.	12-205 Ref. No.
1.	Cap Screw	33009	33009	33009	33009	33009	33009	33009	33009
2.	Lever	92691	92643	92643	92667	92667	86713	88941	88941
3.	Lever Screw	33066	33066	33066	33066	33066	33066	33066	33066
4.	Frog Complete	73989	73997	73997	74003	74003	88828	89062	89062
5.	"Y" Adjusting Lever	16234	16234	16234	16234	16234	71339	71339	71339
6.	Adjusting Nut	34419	34419	34419	34419	34419	12435	12435	12435
7.	Adjusting Nut Screw	34427	34427	34427	34427	34427	34427	34427	34427
8.	Lateral Adjustment Lever	74011	74011	74011	74011	74011	26895	26895	26895
9.	Frog Screw & Washer	78979	78979	78979	78979	78979	78979	78979	78979
10.	Plane Handle	12176	12176	12216	12216	12216	12298	12298	12298
11.	Plane Knob	12192	12192	12232	12232	12232	12305	12305	12305
12.	Handle Screw & Nut	78987	78987	78995	78995	78995	87086	87086	87086
13.	Knob Screw & Nut	79026	79026	79036	79036	79036	87118	87118	87118
14.	Handle Toe Screw	—	—	36396	36396	36396	—	—	—
15.	Plane Bottom	17174	17206	17296	17369	17393	15976	15992	16072
15.	Corrugated Plane Bottom	—	17222	17311	17385	—	—	—	—
16.	Frog Clip & Screw	83043	83043	83043	83043	83043	—	—	—
17.	Frog Adjusting Screw	32864	32864	32864	32864	32864	—	—	—
18.	Cutter	27153	27178	27178	27307	27307	27153	27178	27178
19.	Cap Iron	27356	27364	27364	27389	27389	27356	27364	27364
20.	Double Iron	73818	73834	73834	73859	73859	73818	73834	73834

WHEN ORDERING REPAIR PARTS ALWAYS GIVE THE FOLLOWING INFORMATION:

1. The Reference Number in this List.
2. The Part Name in this List.

STANLEY helps you do things right.™

Block Planes

MADE IN U.S.A.



Key	Part Name	12-019 (9¼) Ref. No.	12-020 (9½) Ref. No.
1.	Plane Knob	12-019-1	12-020-1
2.	Plane Bottom	12-019-2	12-020-2
3.	Cutter Adj. Nut	12-019-3	12-020-3
4.	Back Screw	12-019-4	12-020-4
5.	Lateral Adj. Lever	12-019-5	12-020-5
6.	Cutter	12-019-6	12-020-6
7.	Lever	12-019-7	12-020-7
8.	Lever Screw	12-019-8	12-020-8
9.	Eccentric Plate	—	12-020-9
10.	Finger Rest Knob	12-019-10	12-020-10

Block Planes

MADE IN U.S.A.



Key	Part Name	12-060 (60½) Ref. No.
1.	Plane Bottom	12-060-1
2.	Adjusting Screw Slide Head Assembly	12-060-2
3.	Cutter	12-060-3
4.	Lever	12-060-4
5.	Lever Screw	12-060-5
6.	Eccentric Plate	12-060-6
7.	Finger Rest	12-060-7

Block Planes

MADE IN ENGLAND BY STANLEY



Key	Part Name	12-020 (9½) Ref. No.
1.	Base Assembly	91354
2.	Adjusting Slide Assembly	91508
3.	Lateral Adjustment Lever	91176
4.	Cutter	91881
5.	Lever Assembly	91598
6.	Lever Screw	91281
7.	Front Knob	91824

Block Planes

MADE IN ENGLAND BY STANLEY



Key	Part Name	12-060 (60½) Ref. No.
1.	Base Assembly	91387
2.	Adjusting Slide Assembly	91508
3.	Lateral Adjustment Lever	91176
4.	Cutter	91857
5.	Lever Assembly	91565
6.	Lever Screw	91281
7.	Front Knob	91824

WHEN ORDERING REPAIR PARTS ALWAYS GIVE THE FOLLOWING INFORMATION:

1. The Reference Number in this List.
2. The Part Name in this List.

STANLEY helps you do things right.™

Router Planes

MADE IN ENGLAND BY STANLEY



12-071
(71P)

Key	Part Name	Ref. No.
1.	Depth Gauge Shoe	12-071-1
2.	Plane Iron ¼"	12-071-2
2.	Plane Iron ½"	12-071-2
2.	Plane Iron V	12-071-2
3.	Knob Bolt & Nut	12-071-3
4.	Knob	12-071-4
5.	Cutter Adj. Screw	12-071-5
6.	Cutter Adj. Nut	12-071-6
7.	Cutter Adj. Complete	12-071-7
8.	Plane Bottom	12-071-8
9.	Fence	12-071-9
10.	Fence Screw & Washer	12-071-10
11.	Clamp	12-071-11

Rabbet Planes

MADE IN ENGLAND BY STANLEY



12-078
(78)

Key	Part Name	Ref. No.
1.	Fence	12-078-1
2.	Fence Screw	12-078-2
3.	Adj. Depth Gauge	12-078-3
4.	Depth Gauge Screw	12-078-4
5.	Fence Arm	12-078-5
6.	Spurs with Screw	12-078-6
7.	Lever	12-078-7
8.	Cutter Holder Screw	12-078-8
9.	Adj. Lever & Screw	12-078-9
10.	Plane Iron	12-078-10
11.	Plane Bottom	12-078-11

Block Planes

MADE IN ENGLAND BY STANLEY



12-102
(102)

Key	Part Name	Ref. No.
1.	Base Assembly	92537
2.	Cutter	27826
3.	Lever	91402
4.	Lever Screw	91995

Handyman® Planes

Product Number	Description	Length Inches	Cutter Width Inches
12-003	#3 Handyman Plane	9¼	1¾
12-004	#4 Handyman Plane	9½	2
12-205	#5 Handyman Plane	14	2
12-247	Handyman Block Plane	6⅝	1⅝
12-101	Small Trimming Plane	3½	1
12-102	Trimming Plane		
12-075	Bull Nose Plane	4	13/32
12-078	Regular & Bull Nose	8¼	1½
12-151	Spoke Shave	10	2⅛

Block Planes

MADE IN U.S.A.



12-116
(110)

Key	Part Name	Ref. No.
1.	Plane Bottom	12-116-1
2.	Lever Adj. Assembly	12-116-2
3.	Cutter	12-116-3
4.	Lever	12-116-4
5.	Knob	12-116-5

WHEN ORDERING REPAIR PARTS ALWAYS GIVE THE FOLLOWING INFORMATION:
1. The Reference Number in this List.
2. The Part Name in this List.

STANLEY helps you do things right.™

Block Planes

MADE IN ENGLAND BY STANLEY



12-116 (110)

Key	Part Name	Ref. No.
1.	Base Assembly	92472
2.	Cutter	27875
3.	Lever	91208
4.	Lever Screw	91995
5.	Front Knob	91143

Block Planes

MADE IN U.S.A.



12-118 (118P)

Key	Part Name	Ref. No.
2.	Adjusting Screw Slide Head Assembly	12-118-2
3.	Cutter	12-118-3
4.	Lever	12-118-4

Block Planes

MADE IN U.S.A.



12-220 (220)

Key	Part Name	Ref. No.
1.	Plane Bottom	12-220-1
2.	Adjusting Screw Slide Head Assembly	12-220-2
3.	Cutter	12-220-3
4.	Lever	12-220-4
5.	Lever Screw	12-220-5
6.	Knob	12-220-6
7.	Lever Knob	12-220-7

Block Planes

MADE IN ENGLAND BY STANLEY



12-220 (220)

Key	Part Name	Ref. No.
1.	Base Assembly	90966
2.	Adjusting Slide Assembly	91508
3.	Cutter	91881
4.	Lever Assembly	91598
5.	Lever Screw	91281
6.	Front Knob	91143

Block Planes

MADE IN ENGLAND BY STANLEY



12-247 (H1247)

Key	Part Name	Ref. No.
1.	Base Assembly	91443
2.	Cutter	27875
3.	Lever	92261
4.	Lever Screw	91995

Replacement Plane Irons



DOUBLE

Key	Part Name	WIDTH OF CUTTER 1¾ Inch	2 Inch	2⅜ Inch
1.	Double for Plane	12-003-21	12-004-21	12-006-21

WHEN ORDERING REPAIR PARTS ALWAYS GIVE THE FOLLOWING INFORMATION:

1. The Reference Number in this List.
2. The Part Name in this List.

STANLEY helps you do things right.™

Bolt Cutters

Key	Part Name	14-205 (84-205) Ref. No.
1.	Top Plate	14-205-1

Saw Sets



Key	Part Name	15-042 (42SS) Ref. No.
1.	Plunger	15-042-1
2.	Plunger Spring	15-042-2
5.	Trigger Lever	15-042-5
6.	Trigger Pin	15-042-6
8.	Anvil	15-042-8
11.	Anvil Clamp Screw	15-042-11
12.	Anvil Clamp Screw Washer	15-042-12
13.	Anvil Clamp Spring	15-042-13
15.	Anvil Adj. Cam	15-042-15
16.	Stop	15-042-16
18.	Stop Adj. Nut	15-042-18
19.	Stop Spring	15-042-19
20.	Circular Saw Attachment	15-042-20
21.	Circular Saw Screw	15-042-21
22.	Circular Saw Washer	15-042-22

Coping Saws

Key	Part Name	15-104 Ref. No.	15-106 Ref. No.
1.	Handle	15-104-1	15-106-1
2.	Front Connector	15-104-2	15-106-2
3.	Rear Connector	15-104-3	15-106-3

Hacksaws

Key	Part Name	15-160 Ref. No.	15-170 Ref. No.	15-265 (H1265) Ref. No.	15-408 (408) Ref. No.	15-565 (565) Ref. No.
1.	Front Connector	15-160-1	15-170-1	15-265-1	15-408-1	15-565-1
2.	Rear Connector	15-160-2	15-170-2	15-265-2	15-408-2	15-565-2

WHEN ORDERING REPAIR PARTS ALWAYS
GIVE THE FOLLOWING INFORMATION:

1. The Reference Number in this List.
2. The Part Name in this List.

STANLEY helps you do things right.™

Mitre Boxes



Key	Part Name	19-035 (19-615) Ref. No.
1.	Frame	19-035-1
2.	Length Gauge	19-035-2
3.	¼-20 Neck Bolt	19-035-3
4.	Cutting Board	19-035-4
5.	Spring Wedge	19-035-5
6.	Sleeve Wedge	19-035-6
7.	Wedge	19-035-7
8.	Post Saw Guide	19-035-8
9.	#10-24 Phillips Head	19-035-9
10.	Spring Pin	19-035-10
11.	¼-20 x ½ Neck Bolt	19-035-11
12.	Screw Post	19-035-12
13.	Saw Guide Assembly	19-035-13
14.	#6 x ½ Phillips Screw	19-035-14

Key	Part Name	19-035 (19-615) Ref. No.
15.	Leg Frame	19-035-15
16.	Clamp	19-035-16
17.	¼-20 Wing Nut	19-035-17
18.	Index Plate	19-035-18
19.	6-32 NC Screw	19-035-19
20.	¼-20 Wing Screw	19-035-20
21.	Saw Guide — Right	19-035-21
22.	Saw Guide — Slide	19-035-22
23.	Compression Spring	19-035-23
24.	Insert	19-035-24
25.	Saw Guide — Left	19-035-25
26.	Spacer Spring	19-035-26
27.	¼-20 Thumb Screw	19-035-27
28.	4" x 18" Mitre Saw #15-418	19-035-28
*29.	Saw Guide Wedge	19-035-29

* (Not Shown)

WHEN ORDERING REPAIR PARTS ALWAYS GIVE THE FOLLOWING INFORMATION:

1. The Reference Number in this List.
2. The Part Name in this List.

STANLEY helps you do things right.™

Mitre Boxes



19-060 (60MB)

Key	Part Name	Ref. No.
1.	Board Screw	19-060-1
2.	Spur Screw	19-060-2
3.	Frame (includes Plate)	19-060-3
4.	Catch	19-060-4
5.	Catch Pin	19-060-5
6.	Saw Guide Cylinder Plate	19-060-6
7.	Side Plate Screws (4)	19-060-7
8.	Index Plate Screws (3)	19-060-8
9.	Index Plate	19-060-9
10.	Frame Leg	19-060-10
11.	Leg Screws (2)	19-060-11
12.	Frame Board	19-060-12
13.	Saw Guide Cylinder	19-060-13
14.	Rod (Front or Rear)	19-060-14
15.	Lifting Spring	19-060-15
16.	Saw Guide Stop	19-060-16
17.	Upright Screws	19-060-17
18.	Upright Adj. Screw	19-060-18
19.	Upright Adj. Lock Nut	19-060-19
20.	Upright Adj. Lock Washer	19-060-20
21.	Swivel Complete	19-060-21
22.	Swivel Check Screw	19-060-22
23.	Index Pin Adj. Screw	19-060-23
24.	Index Pointer	19-060-24
25.	Index Pointer Screw	19-060-25
26.	Swivel Washer	19-060-26
27.	Swivel Bushing	19-060-27
28.	Swivel Screw	19-060-28
29.	Index Pin Screw	19-060-29
30.	Index Pin Spring	19-060-30
31.	Index Pin Bushing	19-060-31
32.	Index Pin Stud	19-060-32
33.	Index Pin & Lever	19-060-33
*34.	Upright (complete)	19-060-34

* **(Not Shown)**

Mitre Boxes



19-115 (115)

Key	Part Name	Ref. No.
1.	Saw Guide — Right	19-115-1
2.	Saw Guide — Left	19-115-2
3.	Adjusting Screw	19-115-3
4.	Pivot	19-115-4
5.	Friction Stop Screw	19-115-5
6.	Friction Stop Spring	19-115-6
7.	Friction Stop Shoe	19-115-7
8.	Index Plate	19-115-8
9.	Index Plate Screw	19-115-9
10.	Wedge Pin	19-115-10
11.	Wedge	19-115-11
12.	Holding Spring	19-115-12
13.	Spring Fastening Screw	19-115-13
14.	Pivot Bracket Set Screw	19-115-14
15.	Pivot Bracket Screw — Short	19-115-15
16.	Pivot Bracket Washer	19-115-16
17.	Pivot Bracket Screw — Long	19-115-17
18.	Pivot Bracket	19-115-18
19.	Frame **(Not Available)**	—
20.	Pivot Bracket Screw	19-115-20
21.	Bench Stop Screw	19-115-21
22.	Bench Stop	19-115-22

WHEN ORDERING REPAIR PARTS ALWAYS GIVE THE FOLLOWING INFORMATION:

1. The Reference Number in this List.
2. The Part Name in this List.

STANLEY helps you do things right.™

Mitre Machines



Key	Part Name	Joining Vise 19-100 (100MM) Ref. No.	Joining Vise 19-400 (400) Ref. No.
1.	Bed Plate	19-100-1	—
2.	Bed Plate	—	19-400-2
3.	Threaded Clamp	19-100-3	—
4.	Base w/Hinge	19-100-4	19-400-4
6.	Threaded Clamp	—	19-400-6
7.	Ring	19-100-7	19-400-7
8.	Saw Gauge Screw & Washer	19-100-8	—
9.	Saw Gauge	19-100-9	—
10.	Rule Gauge & Screw	19-100-10	—
11.	Low Clamp	19-100-11	—
12.	Clamp Screw	19-100-12	19-400-12
13.	Collar for Clamp Screw	19-100-13	19-400-13
14.	Hinge Screw & Nut	19-100-14	19-400-14
15.	Hinge Thumb Screw	19-100-15	19-400-15
16.	Ring Thumb Screw	19-100-16	19-400-16
17.	Saw Guide	19-100-17	—
18.	Rule	19-100-18	—
19.	Left & Right Stationary Jaw	19-100-19	—
20.	Stationary Spacer	19-100-20	—
21.	Stationary Jaw Screw	19-100-21	—
22.	Detent Spring	19-100-22	—
23.	Roll Studs with Bushing	19-100-23	—

Mitre Boxes



19-114 (H114A)

Key	Part Name	Ref. No.
1.	Post with Screw	19-114-1
2.	Fame	19-114-2
3.	Saw Guide Complete	19-114-3
4.	Saw Guide Thumb Screw	19-114-4
5.	Wedge Wing Bolt	19-114-5
6.	Wedge	19-114-6

Mitre Boxes



19-116 (116MB)

Key	Part Name	Ref. No.
1.	Bracket Wing Nut Bolt	19-116-1
2.	Bracket Wing Nut	19-116-2
3.	Bracket	19-116-3
4.	Back Plate	19-116-4
5.	Back Plate Screw	19-116-5
6.	Saw Guide Adj. Screw	19-116-6
7.	Clamp "L" Screw	19-116-7
8.	Saw Guide & Index Plate	19-116-8
9.	Board	19-116-9

WHEN ORDERING REPAIR PARTS ALWAYS GIVE THE FOLLOWING INFORMATION:

1. The Reference Number in this List.
2. The Part Name in this List.

STANLEY helps you do things right.™

Mitre Boxes



Key	Part Name	19-160 Ref. No.
1.	Side Plate Screw	19-160-1
2.	Side Plate	19-160-2
3.	Saw Guide	19-160-3
4.	Latch	19-160-4
5.	Pin	19-160-5
6.	Post	19-160-6
7.	#10-32 Square Nut	19-160-7
8.	Stop	19-160-8
9.	#10-32 x ¾" Screw	19-160-9
10.	Swivel	19-160-10
11.	¼"-20 x ⅝" Screw	19-160-11
12.	Spring	19-160-12
13.	Detent Arm	19-160-13
14.	Shoulder Screw	19-160-14
15.	Clamp Knob	19-160-15
16.	Washer	19-160-16
17.	Detent Pin	19-160-17
18.	Lock Nut	19-160-18
19.	Washer	19-160-19

Key	Part Name	19-160 Ref. No.
20.	¼"-20 x ½" Screw	19-160-20
21.	Index Plate	19-160-21
22.	Leg	19-160-22
23.	¼"-20 x ⅝" Screw	19-160-23
24.	Wing Screw	19-160-24
25.	Length Gauge	19-160-25
26.	Spur Screw	19-160-26
27.	Pivot Bolt (Special)	19-160-27
28.	Thumb Screw	19-160-28
29.	Base	19-160-29
30.	Stock Guide	19-160-30
31.	Pointer	19-160-31
32.	#10-24 x 1⅜"	19-160-32
33.	Clamp	19-160-33
34.	Lock Bolt	19-160-34
35.	Lock Washer	19-160-35
36.	Upright Assembly (Front & Rear)	19-160-36
37.	26" x 4" Saw	19-160-37

WHEN ORDERING REPAIR PARTS ALWAYS
GIVE THE FOLLOWING INFORMATION:

1. The Reference Number in this List.
2. The Part Name in this List.

STANLEY helps you do things right.™

Mitre Boxes



Key	Part Name	19-235 (85-235) Ref. No.	19-264 (85-264) Ref. No.	19-306 (85-306) Ref. No.
1.	Screw	19-235-1	19-264-1	19-306-1
2.	Latch Spring	19-235-2	19-264-2	19-306-2
3.	Upright Tie Bar	19-235-3	19-264-3	19-306-3
4.	Latch	19-235-4	19-264-4	19-306-4
5.	Roll Pin	19-235-5	19-264-5	19-306-5
6.	Saw Guide(L&R)	19-235-6	19-264-6	19-306-6
7.	Latch Plate	19-235-7	19-264-7	19-306-7
8.	Post	19-235-8	19-264-8	19-306-8
9.	Square Nut	19-235-9	19-264-9	19-306-9
10.	Stop	19-235-10	19-264-10	19-306-10
11.	Screw	19-235-11	19-264-11	19-306-11
12.	Post Support	19-235-12	19-264-12	19-306-12
13.	Cut Pt. Set Scr.	19-235-13	19-264-13	19-306-13
14.	Swivel — Comp.	19-235-14	19-264-14	19-306-14
15.	Screw	19-235-15	19-264-15	19-306-15
16.	Spring	19-235-16	19-264-16	19-306-16
17.	Detent Arm	19-235-17	19-264-17	19-306-17
18.	Shoulder Screw	19-235-18	19-264-18	19-306-18
19.	Clamp Knob	19-235-19	19-264-19	19-306-19
20.	Flat Washer	19-235-20	19-264-20	19-306-20
21.	Detent Pin	19-235-21	19-264-21	19-306-21
22.	Lock Nut	19-235-22	19-264-22	19-306-22
23.	Flat Washer	19-235-23	19-264-23	19-306-23
24.	Screw	19-235-24	19-264-24	19-306-24
25.	Index Plate	19-235-25	19-264-25	19-306-25
26.	Stock Guide	19-235-26	19-264-26	19-306-26
27.	Leg	19-235-27	19-264-27	19-306-27
28.	Screw	19-235-28	19-264-28	19-306-28
29.	Thumb Screw	19-235-29	19-264-29	19-306-29
30.	Length Gauge	19-235-30	19-264-30	19-306-30
31.	Upright Assmby.	19-235-31	19-264-31	19-306-31
32.	Spur Screw	19-235-32	19-264-32	19-306-32
33.	Pivot Bolt	19-235-33	19-264-33	19-306-33
34.	Thumb Screw	19-235-34	19-264-34	19-306-34
35.	Base Unit	19-235-35	19-264-35	19-306-35
36.	Latch Release	19-235-36	19-264-36	19-306-36
37.	Saw	19-235-37	19-264-37	19-306-37
38.	Wedge	19-235-38	19-264-38	19-306-38
39.	Pointer Unit	19-235-39	19-264-39	19-306-39
40.	Screw	19-235-40	19-264-40	19-306-40
41.	Clamp Pad	19-235-41	19-264-41	19-306-41
42.	Clamp	19-235-42	19-264-42	19-306-42
43.	Carriage Bolt	19-235-43	19-264-43	19-306-43

WHEN ORDERING REPAIR PARTS ALWAYS GIVE THE FOLLOWING INFORMATION:

1. The Reference Number in this List.
2. The Part Name in this List.

STANLEY helps you do things right.™

Mitre Boxes



Key	Part Name	19-246 (2246A) Ref. No.	19-258 (2358A) Ref. No.	2244A Ref. No.
1.	Length Gauge & Screw	19-246-1	19-258-1	2244A-1
2.	Board Screw	19-246-2	19-258-2	2244A-2
3.	Spur Screws	19-246-3	19-258-3	2244A-3
4.	Stop Spring	19-246-4	19-258-4	2244A-4
5.	Stop Spring Screw & Washer	19-246-5	19-258-5	2244A-5
6.	Plunger	19-246-6	19-258-6	2244A-6
7.	Index Plate Screws (3)	19-246-7	19-258-7	2244A-7
8.	Index Plate	19-246-8	19-258-8	2244A-8
9.	Swivel Bushing	19-246-9	19-258-9	2244A-9
10.	Swivel Bushing Screw	19-246-10	19-258-10	2244A-10
11.	Swivel Complete	19-246-11	19-258-11	2244A-11
12.	Clamping Lever Screw	19-246-12	19-258-12	2244A-12
13.	Index Pointer Screws (2)	19-246-13	19-258-13	2244A-13
14.	Index Pointer	19-246-14	19-258-14	2244A-14
15.	Index Clamping Lever	19-246-15	19-258-15	2244A-15
16.	Clamping Lever Spring Screw	19-246-16	19-258-16	2244A-16
17.	Clamping Lever Spring	19-246-17	19-258-17	2244A-17
18.	Index Pin Adjusting Screw	19-246-18	19-258-18	2244A-18
19.	Index Pin	19-246-19	19-258-19	2244A-19
20.	Index Pin Bushing	19-246-20	19-258-20	2244A-20
21.	Index Pin Spring	19-246-21	19-258-21	2244A-21
22.	Index Pin Cam	19-246-22	19-258-22	2244A-22
23.	Clamping Lever Pin	19-246-23	19-258-23	2244A-23
24.	Clamping Pin	19-246-24	19-258-24	2224A-24
25.	Clamping Pin Adjusting Screw	19-246-25	19-258-25	2244A-25
26.	Saw Depth Gauge Stop	19-246-26	19-258-26	2244A-26
27.	Saw Depth Gauge Stop Screw	19-246-27	19-258-27	2244A-27
28.	Saw Depth Thumb Screw	19-246-28	19-258-28	2244A-28
29.	Saw Depth Gauge	19-246-29	19-258-29	2244A-29
30.	Saw Guide Lift Screw	19-246-30	19-258-30	2244A-30
*31.	Saw Guide	19-246-31	19-258-31	2244A-31
32.	Roller Studs	19-246-32	19-258-32	2244A-32
33.	Frame Board	19-246-33	19-258-33	2244A-33
34.	Stock Guide	19-246-34	19-258-34	2244A-34
35.	Leg Screw	19-246-35	19-258-35	2244A-35
36.	Frame Leg	19-246-36	19-258-36	2244A-36
37.	Frame (including Index Plate)	19-246-37	19-258-37	—
38.	Stock Guide Thumb Screw	19-246-38	19-258-38	2244A-38

*** One roller stud on new style box.**

WHEN ORDERING REPAIR PARTS ALWAYS GIVE THE FOLLOWING INFORMATION:

1. The Reference Number in this List.
2. The Part Name in this List.

STANLEY® helps you do things right.™

Replacement Saws for Mitre Boxes

Part Name	19-066 (60MB) Ref. No.	19-246 (2246A) Ref. No.	19-258 (2358A) Ref. No.	85-100 (100MM) Ref. No.	244A Ref. No.	246A Ref. No.	346A Ref. No.	358A Ref. No.	360A Ref. No.	2244A Ref. No.
Replacement Saw...	15-131-1	15-132-1	15-133-1	15-131-1	15-131-1	15-132-1	15-132-1	15-133-1	15-124-1	15-131-1

Replacement Belt Clips for Tape Rules

For Rules	Ref. No.
All 1" Blades and Top Read Rules	33-425-1
All Other Rules	33-312-2

Replacement Slide Locks for Tape Rules

For Rules	Ref. No.
All 1" Rules	33-425-1
33-423	33-423-2
33-116, 33-320	33-116-3
33-310, 33-212	33-310-4
All ½" Rules	33-212-5
All Top Read Rules	33-912-6

Product Knowledge — Customer Benefits

FEATURES	BENEFITS
Positive Lock	Blade will not creep.
Blade protected with Mylar® film	Guarantees longer blade life. Resists abrasion, oils, dirt and most solvents.
Black graduations on LIFE GUARD YELLOW background	Gives highest visibility. More accuracy.
Belt clip attached	Keeps tape rule handy. Prevents loss.
"TRU-ZERO" Hook	Enables precise measuring of both outside areas and harder-to-get-at interiors.
Cartridge replacements (Powerlock® II)	Quick and easy replacement of blade and spring.
Automatic blade control (33-912, 33-916, 33-423, 33-430)	Reduces blade breakage.
Top reading (33-912, 33-916)	Easy to read and use. Great for inside reading and layout work. Reduces possibility of making mistakes.

Cartridge Replacement for Powerlock® II Rules



Drop-in cartridge allows for quick and easy replacement of blade and spring.

SEE PRODUCT CATALOG FOR REPLACEMENT CARTRIDGE.

Replacement Springs for Tape Rules

The replacement of a spring motor is not recommended. However, if it is done, eye protection and work gloves should be worn. The edges of the spring can be sharp.

Warning: A partially or completely wound spring can be dangerous if allowed to unwind rapidly and unrestricted.

Level and Plumb Units

For Machinist's Levels

Key	Part Name	Product 34V Ref. No.	Product 36G Ref. No.
4.	Level Tube	LW34V-4	—
10.	Level Tube	LW34V-10	—
6.	Level Tube with Cover	—	LW36G-6
24.	Level Tube with Cover	—	LW36G-24
6.	Plumb Tube with Cover	—	PW36G-6
24.	Plumb Tube with Cover	—	PW36G-24

WHEN ORDERING REPAIR PARTS ALWAYS GIVE THE FOLLOWING INFORMATION:

1. The Reference Number in this List.
2. The Part Name in this List.

STANLEY helps you do things right.™

Combination Squares



Key	Part Name	46-021 (21S) Ref. No.	46-122 (122) Ref.No.	46-222 (1222½) Ref. No.
1.	Main Body	46-021-1	46-122-1	46-222-1
2.	Blades	46-021-2	46-122-2	46-222-2
3.	Lock Pin & Scr.	46-021-3	46-122-3	46-222-3
4.	Spring	46-021-4	46-122-4	46-222-4
5.	Scriber	46-021-5	46-122-5	46-222-5

Bevels



Key	Part Name	46-800 (18TB) Ref. No.
1.	Bolt	46-800-1
2.	Pivot Screw	46-800-2
3.	Pivot Washer	46-800-3

Bevels



Key	Part Name	46-812 (25TB) Ref. No.
1.	Wing Nut	46-812-1
2.	Bolt	46-812-2

Marking Gauges



Key	Part Name	47-061 (61G) Ref. No.	47-065 (65G) Ref. No.
1.	Main Body	47-061-1	47-065-1
2.	Bar	47-061-2	47-065-2
3.	Thumb Screw	47-061-3	47-065-3
4.	Point	47-061-4	47-065-4
5.	Retaining Screw	—	47-065-5
6.	Brass Shoe	—	47-065-6
7.	Stop Screw	47-061-7	47-065-7

Marking Gauges



Key	Part Name	47-090 (90G) Ref. No.	47-091 (91G) Ref. No.
1.	Main Body	47-090-1	47-091-1
2.	Bar	47-090-2	47-091-2
3.	Thumb Screw	47-090-3	47-091-3
4.	Point	47-090-4	47-091-4

Butt Gauges



Key	Part Name	47-095 (95G) Ref. No.
2.	Double Bar	47-095-2
3.	Single Bar	47-095-3
4.	Thumb Screw	47-095-4

WHEN ORDERING REPAIR PARTS ALWAYS GIVE THE FOLLOWING INFORMATION:

1. The Reference Number in this List.
2. The Part Name in this List.

STANLEY helps you do things right.™

Plumb Bob Tips

Key	Part Name	47-170 (170)	47-171 (171)	47-172 (172)
			Ref. No.	
*1.	Tip		47-170-1	

* Fits ALL

Shingle Hatchet

Key	Part Name	59-135 Ref. No.
1.	Stop Gauge	59-135-1

Yankee® Spiral Ratchet Screwdrivers



Key	Part Name	68-030 (30A) Ref. No.	68-031 (31A) Ref. No.	68-130 (130A) Ref. No.	68-131 (131A) Ref. No.	68-135 (135A) Ref. No.
1.	Spindle & Chuck	68-030-1	68-031-1	68-130-1	68-131-1	68-135-1
2.	Clutch Screw	68-030-2	68-031-2	68-130-2	68-131-2	68-135-2
3.	Lock Collar	68-030-3	68-031-3	68-130-3	68-131-3	68-135-3
4.	Friction Spring	68-030-4	68-031-4	68-130-4	68-131-4	68-135-4
5.	Steel Balls (2)	68-030-5	68-031-5	68-130-5	68-131-5	68-135-5
6.	Sleeve	68-030-6	68-031-6	68-130-6	68-131-6	68-135-6
7.	Nut to Draw	68-030-7	68-031-7	68-130-7	68-131-7	68-135-7
8.	Nut to Drive	68-030-8	68-031-8	68-130-8	68-131-8	68-135-8
9.	Stop	68-030-9	68-031-9	68-130-9	68-131-9	68-135-9
10.	Bushing Stop	68-030-10	68-031-10	68-130-10	68-131-10	68-135-10
11.	Pawls (2)	68-030-11	68-031-11	68-130-11	68-131-11	68-135-11
12.	Shifter	68-030-12	68-031-12	68-130-12	68-131-12	68-135-12
13.	Main Spring	N/A *	N/A *	68-130-13	68-131-13	68-135-13
14.	Spindle Washer	68-030-14	68-031-14	68-130-14	68-131-14	68-135-14
15.	Spring Plug	N/A *	N/A *	68-130-15	68-131-15	68-135-15
16.	Sleeve Screw	68-030-16	68-031-16	68-130-16	68-131-16	68-135-16
17.	Handle	68-030-17	68-031-17	68-130-17	68-131-17	68-135-17

* #13 and #15 are not used on 68-030 or 68-031.

WHEN ORDERING REPAIR PARTS ALWAYS GIVE THE FOLLOWING INFORMATION:

1. The Reference Number in this List.
2. The Part Name in this List.

STANLEY helps you do things right.™

Yankee® Spiral Ratchet Screwdrivers



Key	Part Name	68-133 (133H) Ref. No.	68-233 (233H) Ref. No.
1.	Sleeve	68-133-1	68-233-1
2.	Stop	68-133-2	68-233-2
3.	Nut to Draw	68-133-3	68-233-3
4.	Nut to Drive	68-133-4	68-233-4
5.	Shifter	68-133-5	68-233-5
6.	Pawls (2)	68-133-6	68-233-6
7.	Spring Plug	68-133-7	68-233-7
8.	Main Spring	68-133-8	68-233-8
9.	Cap	68-133-9	68-233-9



Sluggish operation due to lack of lubrication. **Note:** Very often a screwdriver can be repaired by placing a few drops of oil through the shifter button slot.

Yankee® Ratchet Tap Wrenches

Key	Part Name	68-251 (251A) Ref. No.
1.	Chuck Jaws (2)	68-251-1
2.	Chuck Jaw Spring	68-251-2
3.	Pawls (2)	68-251-3
4.	Handle	68-251-4

WHEN ORDERING REPAIR PARTS ALWAYS GIVE THE FOLLOWING INFORMATION:

1. The Reference Number in this List.
2. The Part Name in this List.

STANLEY helps you do things right.™

Garden Tools

For Pruner No. 70-008 (PA8)

Key	Part Name	Ref. No.
1.	Anvil & Screw	70-008-1
2.	Volute Spring	70-008-2
3.	Pivot Bolt, Nut & Washer	70-008-3

Garden Tools

For Pruner No. 70-016 (PA16)

Key	Part Name	Ref. No.
1.	Anvil & Rivet	70-016-1
2.	Spring	70-016-2
3.	Bolt-Nut & Washer	70-016-3

Woodworkers Vise



81-700 (80-700)

Key	Part Name	Ref. No.
1.	Main Jaw	81-700-1
2.	Slide Jaw	81-700-2
3.	Feed Screw & Handle	81-700-3
4.	Retaining Washer	81-700-4
5.	Jaw Face & Screws	81-700-5

Woodworkers Vise



81-702 (80-702)

Key	Part Name	Ref. No.
1.	Main Jaw	81-702-1
2.	Slide Jaw	81-702-2
3.	Feed Screw & Handle	81-702-3
4.	Retaining Washer	81-702-4

UniTrack™ Merchandiser Components



UNITRACK™ COMPONENTS

Key	Part Name	Ref. No.
1.	Pnl. Brkets./Pnl. Lckng. Buttons (2/Bag)	79000105
2.	A) Loop Hook - 6½"	79000174
	B) Loop Hook - 8½"	79000175
	C) Loop Hook - 10½"	79000176
3.	A) Single Pin Hook - 6½"	79000171
	B) Single Pin Hook - 8" (Narrow)	79000276
	C) Single Pin Hook - 8½"	79000172
	D) Single Pin Hook - 10½"	79000173
4.	Heavy Duty Sgle. Pin Hook - 6"	79000295
5.	Heavy Duty Clips (2/Bag)	79000177
6.	Heavy Duty "Y" Fram. Hmr. Hook	79000294
7.	Wall Talker Assembly	75000243

HAMMER
SAFETY RULES

1. Strike squarely — avoid glancing blows.



2. Never strike with side of hammer.

3. Never strike one hammer with another.

4. Always wear safety goggles when hammering.

5. Never use hammer with loose or damaged handle.

6. Discard hammer when face shows excessive wear, mushrooming, chipping, dents, etc.

7. Select proper hammer. Use hammer of suitable size and weight for job. When striking chisels, punches, wedges, etc., hammer face should be ½″ larger than head of struck tool. (For example: a ½″ cold chisel requires at least a 1″ hammer face.)

FOR SAFETY & PERFORMANCE SELECT THE PROPER HAMMER

for common and finishing nails and nail sets.
Not for: masonry nails, cold chisels or other metal.

for cold chisels, punches, rivets and shaping metal.

for cold chisels, brick chisels, star drills, hardened nails, etc.

for holding and driving tacks.

for setting and splitting bricks, tiles, concrete blocks. also for chipping mortar.

for use where steel hammer would mar surface.

for spikes, stakes, cold chisels, hardened nails, etc.

STANLEY®

helps you do things right.®

STANLEY®

STANLEY TOOLS, DIVISION OF THE STANLEY WORKS, DEPT. J M, NEW BRITAIN, CT 06050 U. S. A.

REPAIR PARTS ORDER FORM

TEAR OUT

YOUR NAME AND COMPLETE ADDRESS

(NAME)

(ADDRESS)

(CITY) (STATE) (ZIP CODE)

Quantity	Key	Part Name	Product - Reference No.	Part Price	Total Price
				$	$
		Postage and Handling Charge			2 .50

TOTAL PRICE (Please enclose your check or money order — no cash — for this amount) $

TEAR OUT

When ordering Stanley replacement parts, help us speed up your order by observing the following:

A. Please print or type all information.

B. Fill in your name and complete address including your zip code.

C. Complete all ordering information — particularly product - reference number.

D. Make check or money order payable to Stanley Tools.

E. Detach order, fold along dotted line, seal and mail — no postage necessary — don't forget to enclose your check or money order.

Thank You STANLEY TOOLS

RETURN ADDRESS

(FOLD ALONG DOTTED LINE)

NO POSTAGE NECESSARY IF MAILED IN THE UNITED STATES

BUSINESS REPLY MAIL

FIRST CLASS PERMIT NO. 217 NEW BRITAIN, CT

POSTAGE WILL BE PAID BY ADDRESSEE

STANLEY TOOLS

Division of The Stanley Works

P.O. Box 2080

New Britain, Connecticut 06050-9990

ATTN: DEPT. J M